




Committed To Innovation

**Owner's Manual for the
System 6000, Model #6515**



Contents

Section One: Asepsis Automatic Control	Page 1
Operation and Features	Page 1
Adjustments	Page 2
Section Two: Cleaning and Maintenance of the 6515	Page 6

Section One: Asepsis Automatic Control (Figure 1)

Operation and Features

Arm

The arm is equipped with a pneumatic brake that holds the control head in place. The brake toggle is located on the right underside of the control head, behind the water coolant flow control knobs (see *Figure 1*




Figure 1a




Figure 1b

for location of all controls). To position the arm, pull and hold the toggle forward, move the arm to position the head, then release the toggle.

It may be necessary to adjust the spring tension on the arm, depending on how much weight is on the instrument tray. If the control head drifts out of position when the brake is released, see the section below on adjustments.

Handpiece Holders

The handpiece holders on the control head are automatic. With the master air toggle in the on position, the handpiece may be activated by depressing the foot control. Speed is also regulated with the foot control.

The position of the handpiece holders is adjustable. See the section below on adjustments.

Autoclavable Syringe

The 6515 control head comes with a deluxe autoclavable syringe. The holder for the syringe is on the far left side of the tool bar. An instruction booklet is provided.

Controls

The **master on-off toggle** activates the air and water automatic shut-off valves that supply air and water to the entire system. On the underside of the control head, it is located on the left side toward the front.

There is a **water coolant flow control knob** for each of the three handpieces, also located on the underside of the control head, along the right front side. They are arranged in the same order as the handpiece holders\tubings.

The **toggle for the pneumatic arm brake** is on the right underside of the control head, next to the water coolant flow control knobs.

The **air coolant flow control knob** is on the right side of the control head, toward the back.

The **drive air pressure controls** are located inside the control head, on the control block. Drive air pressure and coolant flow should be adjusted according to the handpiece manufacturer's specifications.

The **handpiece flush toggle** is located behind the master on-off. Handpiece tubings can be purged of contaminants and debris by activating this toggle. See the section on cleaning and Maintenance for instructions.

For **access to the inside of the control unit**, locate two screws on the underside of the unit, toward the front. Use a 1/8" hex key to remove the screws. The cover of the unit can now be raised to expose the control block, pressure gauge and plumbing.

Adjustments

Syringe Block

Adjustments to the syringe air and water flow are made on the syringe block. The block is located inside the control head, in front of the drive air pressure gauge (See *Figure 3*).

Turn the hex nuts clockwise for less air or water flow, counter-clockwise for more air or water flow. Use the 3/32" ball driver provided with the unit.

Handpiece Holders

The handpiece holders are attached to the tool bar with two set screws. To reposition a holder, loosen the screws in the bottom of the holder, position as desired, and retighten the screws. You will

Note

Do not use powdered cleansers, scouring pads, or abrasive scrubbers on any of the finished metal surfaces in this system (for example, the autoclavable syringe or the foot control disc). Sodium Hypochlorite will also damage these surfaces.

Control Head

The control head and other components of the system can be cleaned with any commonly available surface disinfectant.

Handpiece Flush

The handpiece flush toggle runs a larger than normal amount of system water through the handpiece tubings, and through the handpieces if they are attached.

To flush the system, hold all of the water-cooled handpieces (or the tubings if the handpieces are not attached) over a basin or sink. Make sure the water will be directed into the receptacle. Pull and hold the flush toggle to the on position. The toggle snaps back to the off position when released. The Center for Disease Control and the American Dental Association can provide recommendations on when to flush your system, and for how long.

need a 3/16" hex key.

Arm Spring Tension

To adjust the tension in the arm spring, extend the arm fully and position it as far above the floor as possible. Using a 5/64" hex key, remove the access plate from the underside of the top section of the arm (see *Figure 2*). Slide the long plastic strip out to expose the tubing

running inside the arm. An opening under the tubing provides access to the spring and to the brass tension adjustment collar.

Spring tension is adjusted by turning the collar. To turn the collar, insert a flat bladed screwdriver into one of the vertical slots. Gently pry against the edge of the opening in the arm until the collar turns.




Figure 2

If the control head drifts up, tension is too high. Turn the collar counter-clockwise. If the control head drifts down, turn the collar clockwise to increase tension.

Turn the collar two or three complete turns. Then, release the brake and see if the control head moves. Continue adjusting in increments of two or three turns as needed.

Handpiece Coolant Flow Control**Note**

All of the following adjustments should be made with a bur in the handpiece. Running a handpiece without a bur installed can damage the handpiece.

Air and water coolant adjustments are made with the air and water coolant flow control knobs. Your handpieces must be in place in order to make these adjustments.

Install a bur in one of the handpieces.

Air Coolant

Place the wet/dry foot control toggle in the dry position (away from the blue dot).

Press on the foot control disc until the handpiece is running at half speed. While the handpiece is running, turn the air coolant flow control knob to provide a strong flow of air. Turn the knob counterclockwise to increase the flow; turn it clockwise to decrease the flow. This adjustment affects all three handpieces.

Water Coolant

Water coolant flow adjustments are made independently for each handpiece.

To adjust water coolant flow, move the wet/dry toggle on the foot control to the wet position (toward the blue dot).

Press on the foot control disc until the handpiece is running at half speed.

While the handpiece is running, turn the corresponding water coolant flow control knob to provide a fine mist of water around the bur (the knobs are arranged across the bottom of the control head in the same order as the handpiece holders/tubings). Very little water coolant is required. Turn the knob counterclockwise to increase the flow, clockwise to decrease the flow.

Repeat this procedure for the other two handpieces.

Drive Air Pressure

You will need a small, flat bladed screwdriver to make this adjustment.

To determine the recommended drive air pressure for your handpieces, refer to the handpiece manufacturer's literature.

Drive air adjustment screws are located on the control block, inside

the control head.

Remove the screws and lift the cover of the control head to expose the control block. The drive air pressure gauge is next to it (*Figure 3*).

Install a bur in the handpiece you are going to adjust. Trace the tubing from the handpiece to the control block to determine which adjustment screw will affect the handpiece you have selected. Position the screwdriver in the adjustment screw. Press on the foot control disc until the handpiece is running at maximum speed.

Turn the adjustment screw counter clockwise until the pressure gauge reads a little higher than the manufacturer's recommendation. Then turn the screw clockwise until the gauge indicates the recommended pressure.


If you do not have an in-line gauge, adjust handpiece pressure until the gauge in the control head reads slightly higher (10psi) than the handpiece manufacturer's recommendation.

Repeat this procedure for each handpiece.

Foot Control

Pressure to any part of the foot control disc provides drive air to the active handpiece. Increased pressure provides increased drive air. Stepping on the foot control also turns on air and water coolant.

Water coolant can be shut off by flipping the wet/dry toggle on the foot control to the off position (away from the blue dot).



Section Two: Cleaning and Maintenance